

BINDING WITH FAUX PIPING Jamis Kresyman

1. Cut binding strip 1 1/2" wide. Cut strip for piping 1 3/4" wide.
2. Join binding and piping strips with diagonal seams the length needed for going around your quilt.
3. Join the long strips of binding and piping with right sides facing and press toward binding fabric. Stagger any diagonal seams with the 2 strips to eliminate bulk.
4. Fold binding in 1/2 with raw edges aligned.
5. Attach binding (with piping being the "wrong" side) to the BACK of the quilt mitering corners and finishing as usual.
6. Press binding away from quilt with seam allowances going away from quilt.
7. Fold binding to the front of the quilt. Stitch in the ditch between piping and binding.